

HCW CITY SPRAYER

Quick and efficient spreading of salt solutions on slippery bike paths, footpaths, pedestrian streets and the like.
Hopper capacity: 100 - 600 liters



– de-icing of roads!

EPOKE HCW CITY SPRAYER

Efficient liquid sprayer

The Epoke/HCW CITY SPRAYER is intended for installation in three-point suspension or directly on a mini-tractor and is easy to maneuver.

The liquid spreader is width and quantity compensated as well as road-speed related (synchronous), which means that the adjusted spreading quantity per m² remains constant irrespective of changes in spreading width or vehicle speed.

Drive by connection to electrical pump (not synchronous), vehicle hydraulics or PTO.

The Epoke/HCW CITY SPRAYER features robust mechanics, synthetic components, accurate computer-controlled dosing and a protected spray bar. All mechanical parts are placed on the rear of the spreader, which leaves it easy to operate and service.

All spreader functions are controlled by the remote control in the driver's cab, which also makes data collection through EpoLink possible.

The spreader features a standard spreading width of 1 meter. By means of optional right and left side nozzles the spreading width may be increased to 3 m (1 m at either side).

The spreading of a salt solution (NaCl) is the most eco-friendly type of slippery roads control in urban areas frequented by cyclists and pedestrians, as liquid spreading reduces the salt consumption considerably.

Liquid spreading provides a quick thawing effect and thus a better friction for cyclists and pedestrians. The liquid is distributed evenly and works its way through the frozen surface.

Hopper capacity: 100 - 600 liters

Spreading width: 1 / 2 / 3 m

Spreading quantity: 5 - 50 ml/m² – stepless adjustment

Road-speed related: 0 - 20 km/h



Hand-held lance sprayer and 12 m hose drum for hard-to-reach places, such as stairs or shop entrances etc.



The construction of the spreading bar offers protection for pipes and nozzles and ensures accurate liquid spraying.



Remote control for installation inside the driver's cab. Controls start/stop of spreading as well as adjustment of spreading quantity.



Epoke® A/S
Vejenvej 50, Askov
DK-6600 Vejen
Tel. +45 76 96 22 00
Fax +45 75 36 38 67
epoke@epoke.dk
www.epoke.dk



In order to maintain the high and uniform product standard Epoke® A/S has been certified by Lloyd's register to ISO 9001:2000.
TLG B-3 approval
GS approval
E1 approval
RoHS directive
WEEE directive

